

How to hang peel and stick wallpaper

Discover how to hang peel and stick wallpaper with our helpful 4 step installation guide.





Make a Guide for Your First Piece

Beginning on the left side of your wall, measure out from the corner the width of the paper (20&1/2") and mark the wall lightly with a pencil. Put your level on this mark and draw a straight, level, vertical line.

Apply Peel-and-Stick Wallpaper

Peel off about 12 inches of the adhesive backing and line the wallpaper up with your lines. Moving from top to bottom, press and smooth the wallpaper against the wall while peeling off the remaining backing. Using downward strokes, run a plastic smoothing tool along the wall to remove air bubbles.





Match Patterns and Repeat

Line up the wallpaper's pattern to ensure a seamless look. Overlap the second piece slightly with the first and run the smoothing tool along the seam to make it lay as flat as possible. Trim at the bottom as needed and repeat to cover the entire surface.

Apply Peel-and-Stick Wallpaper

Peel off about 12 inches of the adhesive backing and line the wallpaper up with your lines. Moving from top to bottom, press and smooth the wallpaper against the wall while peeling off the remaining backing. Using downward strokes, run a plastic smoothing tool along the wall to remove air bubbles.

